



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1427	1810A 1	CLAMP BRACKET ASSEMBLY	2	
2		22477A 1	THUMB SCREW ASSEMBLY	2	
3	12	26227	WASHER, THUMB SCREW	2	
4		30664	TUBE, TILT - CLAMP BRACKET T	1	
5	15	30497A 1	SHIM, CLAMP BRACKET TO SWI	2	
6	11	30499	NUT, TILT TUBE	2	
7		30498	CAP, PLASTIC - TILT TUBE	2	
8	17	33985A 1	SWIVEL PIN AND TOP YOKE ASS	1	
9		30711	BUMPER, TOP YOKE	1	
10	10	33986	SCREW, UPPER MOUNT TO SWI	2	
11		33840	BRACKET, STEERING ARM - SWI	1	
12		34255	BUMPER, STEERING ARM BRAC	1	
13	10	21625	SCREW, STEERING ARM BRACK	3	
14		33963	BRACKET, REMOTE STEERING	1	
15	10	26632	SCREW, REMOTE BRACKET TO	2	
16		33969	PLATE, FRICTION - CO-PILOT (Sv	1	
17	10	34439	SCREW, FRICTION PLATE TO SV	2	
18	38	31061	SERIAL PLATE	1	
19	10	25612	SCREW, DRIVE - SERIAL PLATE	4	
20	1455	2211A 3	SWIVEL BRACKET ASSEMBLY	1	
21	26	32911	OIL SEAL, SWIVEL BRACKET	2	
22	22	23612	FITTING, PREASE - SWIVEL BR	1	
23		29359	LUBRICAP, SWIVEL BRACKET RE	1	
24		35402	YOKE, BOTTOM	1	
25	12	25176	WASHER, SWIVEL PIN TO BOTT	1	
25	12	26837	WASHER, SWIVEL PIN TO BOTT	AR	
26	11	28202	NUT, RETAINING - SWIVEL PIN	1	
27		20215	LEVER, TILT STOP - STARBOARD	1	
28		26864	LEVER, TILT STOP - PORT SIDE	1	
29	10	20217	SCREW, ANCHOR - TILT STOP LI	2	
30	23	20216	SPACER, TILT STOP LEVER	2	
31	10	29237	SCREW, RETAINING - TILT STOF	2	
32	15	37711	SHIM, RETAINING SCREW - POR	1	
33	13	36076	WASHER, WAVE _ RETAINING S	1	
33	13	20846	WASHER, WAVE - RETAINING SI	1	
34	11	24652	NUT, ANCHOR AND RETAINING	4	
35	10	26483	BOLT, CLAMP BRACKET TO BOA	2	
36	12	26485	WASHER, CLUMP BRACKET BOL	2	
37	11	26484	NUT, CLAMP BRACKET BOLT	2	
38		26903A 2	REVERSE LOCK ASSEMBLY	1	
38		20208	SHAFT, REVERSE LOCK TO SWI	1	