



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	28	30250	KEY, FLYWHEEL	1,...		
1	28	45554	KEY, FLYWHEEL	,1,1,1		
2	422	2186	CRANKSHAFT	1,1,1,1		
3	533	2034A 2	MAIN BEARING ASSEMBLY, VAL	1,...		
4	17	20032	DOWEL PIN, MAIN BEARING	10,...		
5	10	25313	SCREW, MAIN BEARING CLAMP	2,...		
6	11	29469	NUT, MAIN BEARING CLAMPIN	2,...		
3	533	2798A 2	MAIN BEARING ASSEMBLY, VAL	1,...		
4	17	20032	DOWEL PIN, MAIN BEARING	,10,...		
5	10	45775	SCREW, MAIN BEARING CLAMP	2,...		
6	11	45774	NUT, MAIN BEARING CLAMPIN	2,...		
3	533	2761A 2	MAIN BEARING ASSEMBLY, VAL	,1,1		
4	17	20032	DOWEL PIN, MAIN BEARING	,10,10		
5	10	45775	SCREW, MAIN BEARING CLAMP	,2,2		
6	11	45774	NUT, MAIN BEARING CLAMPIN	,2,2		
7	34	32203A 1	REED SET, MAIN BEARING (MAT	1,1		
7	34	45506A 1	REED SET, MAIN BEARING (MAT	,1,1		
8	34	31240	REED STOP, MAIN BEARING RE	4,4,4,4		
9	10	29465	SCREW, REED STOP MOUNTING	4,4,4,4		
10	11	29469	NUT, REED STOP MOUNTING SC	4,4,4,4		
11	611	1885A 4	CONNECTING ROD ASSEMBLY	2,...		
12	10	20060	SCREW, CONNECTING ROD	4,...		
13	11	20061	NUT, CONNECTING ROD SCRE	4,...		
14	29	38586	BEARING, NEEDLE-CRANKPIN	64,...		
15	29	39656	BEARING, NEEDLE-PISTON PIN	58,...		
16	12	29681	WASHER, NEEDLE BEARING R	4,...		
11	617	2768A 2	CONNECTING ROD ASSEMBLY	,2,...		
12	10	45739	SCREW, CONNECTING ROD	,4,...		
13	11	20061	NUT, CONNECTING ROD SCRE	,4,...		
14	29	38586	BEARING, NEEDLE-CRANKPIN	,64,...		
15	29	39656	BEARING, NEEDLE-PISTON PIN	,58,...		
16	12	45741	WASHER, NEEDLE BEARING R	,4,...		
11	617	2768A 3	CONNECTING ROD ASSEMBLY	,2,2		
12	10	45739	SCREW, CONNECTING ROD	,4,4		
13	11	20061	NUT, CONNECTING ROD SCRE	,4,4		
14	29	47897	BEARING, NEEDLE-CRANKPIN	,64,64		
15	29	39656	BEARING, NEEDLE-PISTON PIN	,58,58		
16	12	45741	WASHER, NEEDLE BEARING R	,4,4		
17	741	2696A 2	PISTON AND PISTON PIN ASSEM	2,...		
18	40	32118	LOCK RING, PISTON PIN	4,...		
19	29	29100A 1	RING, PISTON	1		