



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		30269A 2	FUEL PUMP ASSEMBLY	1,1,1,1		
2	21	30430A 1	CHECK VALVE ASSEMBLY	1,1,1,1		
3		23014A 1	DIAPHRAGM KIT	1,1,1,1		4
4			GASKET, CHECK VALVE TO	2,2,2,2		4
5			GASKET, FUEL PUMP	2,2,2,2		4
6			GASKET, FUEL PUMP COVE	1,1,1,1		4
7		23004	RETAINER, CHECK VALVE	1,1,1,1		
8	10	20037	SCREW, RETAINER TO HOUSI	2,2,2,2		
9		30275	COVER, FUEL PUMP	1,1,1,1		
10	10	30274	SCREW, FUEL PUMP MOUNTING	2,2,2,2		
11	10	38036	SCREW, FUEL PUMP MOUNTING	1,1,1,1		
12	22	22949	CONNECTOR, PUMP INLET TO F	1,1,1,1		
13	22	22946	SLEEVE, RUBBER-CONNECTOR	1,1,1,1		
14	22	22948	NUT, CONNECTOR TO FUEL LINI	1,1,1,1		
15	32	45182	FUEL LINE, FUEL PUMP TO ADAF	1,1,1,1		
16		22833	ADAPTOR, CHECK UNIT (FUEL P	1,1,1,1		
17		23069	STEM, CHECK UNIT ADAPTOR	1,1,1,1		
18	25	20415	"O" RING, ADAPTOR STEM	1,1,1,1		4
19	24	23067	SPRING, ADAPTOR STEM	1,1,1,1		
20		30188	CUP WASHER, ADAPTOR	1,1,1,1		
21	10	22421	SCREW, ADAPTOR TO BOTTOM	2,2,2,2		
22	11	46887	NUT, ADAPTOR SCREW	2,2,2,2		
23	32	34243	FUEL LINE, FUEL PUMP TO CARB	1,1,1,1		