



14331

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	3406	9622T 6	BRACKET, Clamp (Starboard) (Star)	1		
2	3406	9623 1	BRACKET, Clamp (Port) (Port)	1		
3	10	95373	BOLT	1		
4	12	95375	WASHER	2		
5	12	16192	WASHER	1		
6	11	815088	NUT, (M8)	1		
7		16193	DISTANCE PLATE	1		
8	10	16194	SCREW	2		
9	24	16195 1	SPRING	1		
10	10	16196	SCREW	1		
11	12	16197	WASHER	1		
12		16198	THRUST ROD	1		
13	24	815093 1	SPRING	1		
14	10	16200	CLAMP SCREW ASSEMBLY	2		
15	12	95379	PAD	2		
16	3407	813029T 1	SWIVEL BRACKET	1		
17	22	824969	FITTING, Grease	2		
18	10	823042 23	BOLT	2		
19	10	823042 30	BOLT	4		
20	23	824966	BUSHING (Upper)	1		
21	23	824967	BUSHING (Lower)	1		
22		16204	THRUST PLATE	2		
23	10	16206 1	ADJUSTING SCREW	1		
24	24	95383 8	SPRING	1		
25	12	16826	WASHER	1		
26		16205 1	FRICTION PLATE	2		
27		825112A 2	TILT STOP ASSEMBLY	1		
28		16208 1	GRIP	1		
29		825113	BUSHING	2		
30		16210	SET PLATE	1		
31	10	16211 1	BOLT	2		
32	24	16212	SPRING	1		
33		16213	REVERSE LOCK ARM	1		
34	24	16215	SPRING (Right)	1		
35	24	16216	SPRING (Left)	1		