



1696

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	262	815024	FLYWHEEL	1		
2		16058T	EXCITER COIL	1		
3	10	16059	SCREW	2		
4	54	16060	CLAMP	1		
5	10	16821	SCREW	1		
6	11	16071	NUT	1		
7	12	16072	WASHER	1		
8		16066	PULSER COIL	1		
9	10	16067	SCREW	2		
10		16064A	IGNITION COIL	1		
11	85	855543	PLUG CAP, (with Resistance)	1		
12	10	16705	BOLT, (M6 x 20)	2		
13	13	16818	LOCKWASHER	2		
14	12	809931044	WASHER	2		
15	25	16068	GROMMET	1		
16		16061T04	C.D. UNIT	1		
17		878061	FRONT DAMPER	1		
18		878062	DAMPER (Rear)	1		
19	18	815026	COTTER PIN	1		
20		16074T	ALTERNATOR (Sailpower/Sailmate)	1		
21	10	16059	SCREW (Sailpower/Sailmate)	2		
22	54	16060	CLAMP (Sailpower/Sailmate)	1		
23	10	16821	SCREW (Sailpower/Sailmate)	1		
24		16076A	RECTIFIER KIT (Sailpower/Sailmate)	1		
25	89	16077	FUSE (Sailpower/Sailmate)	1		
26	10	16123	SCREW, (25mm) (Sailpower/Sailmate)	1		
27	13	16079	LOCKWASHER (Sailpower/Sailmate)	1		
28	12	16080	WASHER (Sailpower/Sailmate)	1		
29	54	813275	CLAMP (Sailpower/Sailmate)	1		
30	11	16081	NUT (Sailpower/Sailmate)	1		
31	84	16822	BATTERY CABLE (Sailpower/Sailmate)	1		
32	25	16823	GROMMET (Sailpower/Sailmate)	1		
33	84	16082	EXTENSION HARNESS (Sailpower/Sailmate)	1		
34	87	823037A04	EMERGENCY STOP SWITCH ASSEMBLY	1		
35		823054	LANYARD	1		