

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
0	91	83166M	BEARING MANDREL KIT	1		
0	91	83165T	PULLER ASSEMBLY	1		
0	91	31229A 7	BEARING REMOVAL AND INSTAL	1		
0	91	58222A 1	DIAL INDICATOR KIT	1		
0	91	89045 1	ADAPTOR TOOL	1		
0	91	24937A 1	HOLDER TOOL	1		
0	91	24937A 1	HOLDER TOOL	1		
0	91	83164M	FLYWHEEL PULLER	1		
0	91	99750A 1	MULTI METER	1		
0	91	24697	EXPANDER TOOL	1		
0	91	24161	CAP TOOL	1		
0	91	27780	PULLER	1		
0	91	29287	GAUGE TOOL	1		
0	91	850439T 1	TESTER (EIGHT CHAMBER)	1		
0	91	63998A 1	GAP TOOL (SINGLE CHAMBER)	1		
0	91	99379	TIMING LIGHT	1		
0	91	66274	TORQUE WRENCH, (0-150 lb-in)	1		
0	91	37241	PULLER PLATE	1		

NO IMAGE