



5333

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	1599	825134A 1	DRIVESHAFT HOUSING	1	(Short)	
1	1599	825136A 1	DRIVESHAFT HOUSING	1	(Long)	
2	23	16114	BUSHING	1		
3	10	823042 24	BOLT	6		
4	19	803592	FLUSH PLUG	1		
5	27	95220	GASKET	1		
6	27	16115	GASKET	1		2
7	17	16119	PIN, Dowel	2		
8	25	16118 1	GROMMET	1		
9	25	16117	GROMMET	1		
10		827663A 1	HOUSING	1		
11		16121	RETAINER	1		
12	10	16122	SCREW	2	(Short)	
12	10	16123	SCREW, (25mm)	2	(Long)	
13	1668	825132T17	GEAR HOUSING	1	(Basic)	
13	1668	9621T 6	GEAR HOUSING	1	(Basic-Sailpower/Sailmate)	
14	23	16124	BUSHING	1		
15		823912	ANODE	1	(Round)	
15		875208	ANODE	1	(Square)	
16	10	16832	BOLT, (M6 x 16)	1		
17	22	95368 3	PLUG	2		
18	27	95220	GASKET	2		15
19	10	16125 1	BOLT (Front)	1		
20	12	16826	WASHER	1		
21	10	16126	BOLT (Rear)	1		
22	12	16192	WASHER	1		
23		16133	WATER STRAINER	1		
24	10	16134	SCREW	1		
25	30	16128	BEARING, Ball	1		
26	30	16132	BEARING	1		
27	26	16130	SEAL, Oil	1		15
28	25	16131	O-RING	1		15
29		825118T	HOUSING	1		
30	10	824832 4	SCREW, (M6 x 16)	2		
-	1668	825132T15	GEAR HOUSING, Complete	1	(Short)	
-	1668	825132T16	GEAR HOUSING, Complete	1	(Long)	
-	1668	9621T 5	GEAR HOUSING, Complete	1	(Sailpower/Sailmate)	
-	27	16115A 1	GASKET SET, Powerhead	1		
-	27	95220A 2	SEAL KIT, Gear Housing	1		