



8124

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	114	803580T 1	TOP COWL	1	(Black)	
1	114	803580T 2	TOP COWL	1	(Silver)	
1	114	803580T 4	TOP COWL	1	(Black)(Use With Integral Fuel Tank)	
1	114	803580T 5	TOP COWL	1	(Silver)(Use With Integral Fuel Tank)	
2		810751 2	SEAL	1		
3	25	16228 2	SEAL, Rubber	1		
4	4000	803578T	BOTTOM COWL	1		
4	4000	803578T 1	BOTTOM COWL	1	(Use With Integral Fuel Tank)	
5	37	815693 1	DECAL, Fuel Lever, Remote Fuel S	1	(Use With Integral Fuel Tank)	
6	37	879706	DECAL, Fuel Lever	1	(Use With Integral Fuel Tank)	
7	25	16226	GROMMET	1		
8	25	16225	GROMMET	1		
9	25	16231	GROMMET	1		
10	10	16832	BOLT, (M6 x 16)	4		
11	12	16826	WASHER	4		
12	25	95387 1	GROMMET	1		
13		803579	COVER HOOK	1		
14	10	16211 1	BOLT	1		
15	12	95392 1	WASHER	1		
16	13	16221	WAVE WASHER	1		
17	23	16220	BUSHING	1		
18	26	16219	SEAL	1		
19		16218 1	HOOK LEVER	1		
20		<a href="#">16841A 2</a>	FLUSHING ATTACHMENT	1		
21	91	803581	TOOL KIT	1		
22	50	16230	SAFETY ROPE	1		
23	37	856985 18	DECAL-EPA INFORMATION	1	(1999)	22
23	37	804651A00	DECAL-EPA INFORMATION	1	(2000)	22
23	37	804651A01	DECAL-EPA INFORMATION	1	(2001)	22
23	37	804651A02	DECAL-EPA INFORMATION	1	(2002)	22
23	37	804651A03	DECAL-EPA INFORMATION	1	(2003)	22
23	37	804651A04	DECAL-EPA INFORMATION	1	(2004)	22
23	37	804651A05	DECAL-EPA INFORMATION	1	(2005)	22
24	54	813275	CLAMP	1		
25	10	16827	SCREW	1		
-	37	824087 7	DECAL, Fuel Lever	1		