



1699

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		16837A	2 ALTERNATOR KIT	1		
2		16074T	ALTERNATOR	1		
3	10	16059	SCREW	2		
4	54	16060	CLAMP	1		
5	10	16821	SCREW	1		
6	84	17175	HARNESS	1		
7		16838A	4 BATTERY CHARGING KIT, Rectifi	1	(6 AMP)	
8		16076	RECTIFIER	1	(Use with 20MM Screw)	
8		16076A	1 RECTIFIER KIT	1	(Use with 25 MM Screw)	
9	89	16077	FUSE	1		
10	10	16123	SCREW, (25mm)	1	(25MM)	
10	10	16078	SCREW	1	(20MM)	
11	13	16079	LOCKWASHER	1		
12	12	16080	WASHER	1		
13	54	813275	CLAMP	1		
14	11	16081	NUT	1		
15	84	16082	EXTENSION HARNESS	1		
16		16839A	4 GUIDE KIT, Vertical Rope	1		
17		NSS	Not Sold Separate, Guide	1		
18		16113	SEAL PLATE	1		
19	10	17173	SCREW	4		
20		853828	HANDLE	1	(0.8M)	
20		853828	1 HANDLE	1	(1.0M)	