


Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		16908A	REMOTE CONTROL	1	(Manual Start)	
1		16910A	HOUSING KIT, Front, With Deca	1		
2	19	89774	PLUG	1		
3		17192	PLUG, Stop Switch Hole	1		
4		17191	PLUG, Wire Harness Hole	1		
5		16917	COVER	1		
6		16899	HOLDER, Neutral Lock	1		
7	10	40118107	SCREW, (M5 x 18)	7		
8	13	16923	LOCKWASHER, External	2		
9		16913T	HAND LEVER	1		
10		16916A	CAP ASSEMBLY, With Decal	1		
11		16921	BRACKET, Lock Bar Support	1		
12	10	40056 85	SCREW, (M4 x 10)	2		
13		16915	LOCK ARM	1		
14	10	40056105	SCREW, (M5 x 10)	1		
15	24	16924	SPRING	1		
16		16914	GRIP	1		
17		17016	PLUG	1		
18	10	40116110	SCREW, (M6 x 110)	3		
19	12	35280	WASHER, (.255 x .620 x .030)	3		
20	11	40119 6	NUT, (M6)	3		
21		16920	BRAKE ADJUSTER	1		
22	12	16896	WASHER	1		
23	53	13194	RING, Retaining	1		
24		16895	ARM ASSEMBLY, Brake	1		
25	23	16875	BEARING (1.750 ID)	2		
26	12	16874	WASHER	1		
27		16892T	DRIVE GEAR	1		
28		850724A 2	PLATE/STUD ASSEMBLY	1		
29		16873	ROLLER, Cam	1		
30	10	40071 54	SCREW, (M8 x 30)	1		
31	12	12038	WASHER	1		
32	54	85899A 1	CLIP ASSEMBLY	2		
33	11	40138 6	NUT, (M6)	2		
34		16918A 3	GEAR SHIFT ASSEMBLY	1		
35	23	16868	BEARING (.750 ID)	1		
36	12	16870	WASHER	1		
37	24	16882	SPRING	5		
38		16879	ROLLER, Detent	1		
39		16880	CLIP	1		
40	10	40056 82	SCREW, (M4 x 6)	2		



8143