



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		16837A 2	ALTERNATOR KIT	1		
2		16074	ALTERNATOR	1		
3	10	16059	SCREW, ALTERNATOR	2		
4	54	16060	CLAMP, ALTERNATOR	1		
5	10	16821	SCREW, ALTERNATOR CLAMP	1		
6		16838A 2	RECTIFIER KIT	1		
7		16076	RECTIFIER	1		
8	89	16077	FUSE	1		
9	10	16078	SCREW, RECTIFIER	1		
10	13	16079	LOCKWASHER, RECTIFIER SCREW	1		
11	12	16080	WASHER, RECTIFIER SCREW	1		
12	54	95306	CLAMP, RECTIFIER	1		
12	54	813275	CLAMP, RECTIFIER (SAIL POW)	1		
13	11	16081	NUT, RECTIFIER SCREW	1		
14	84	16822	BATTERY CABLE	1		
15	25	16823	GROMMET	1		
16	84	16082	EXTENSION HARNESS	1		
17		16839A 2	VERTICAL ROPE GUIDE KIT	1		
18		16112	VERTICAL STARTING DEVICE	1		
19		16113	SEAL PLATE	1		
20	10	16827	SCREW, VERTICAL STARTING	4		
21	12	16826	WASHER, VERTICAL STARTING	4		
22		16841A 2	FLUSHING ATTACHMENT	1		
23	84	17175A 2	LIGHTING HARNESS KIT	1		
24		84125M	LIGHTING REGULATOR KIT	1		