



			Parts List			
Ref	Class	Part	Description	Qty	Comment	Footnote
1		16840A 2	REMOTE CONTROL ATTACHING KIT	1		
2		16848	LEVER, THROTTLE WIRE	1		
3		17034	THROTTLE WIRE	1		
4	10	16223	BOLT, THROTTLE WIRE LEV	1		
5	13	16819	LOCKWASHER, THROTTLE W	1		
6	12	16224	WASHER, THROTTLE WIRE	1		
7	23	16849	COLLAR, THROTTLE WIRE LI	1		
8	84	17035	HARNESS (DUEL STOP SWIT	1		
9	17	17031	LOCK PIN	1		
10	17	17033	PIN, LOCK PIN	1		
11	24	17032	SPRING, LOCK PIN	1		
12		17030	SLEEVE	1		
13	12	17029	WASHER, CAP SPRING	2		
14		16847	THROTTLE LEVER	1		
15		17026	BRACKET	1		
16		17027	CAP, BRACKET	1		
17	24	17028	SPRING, BRACKET CAP	1		
18	13	16221	LOCKWASHER, THROTTLE L	1		
19	26	16219	SEAL, THROTTLE LEVER	1		
20	23	16220	BUSHING, THROTTLE LEVEF	1		
21		17023	BRACKET	1		
22	10	16832	BOLT, BRACKET	2		
23	13	16819	LOCKWASHER, BRACKET BO	2		
24	11	16825	NUT, BRACKET BOLT	2		
25		17024	STEERING HOOK PLATE	1		
26	10	17022	BOLT, PLATE	2		
27	12	16192	WASHER, PLATE BOLT	2		
28	13	17025	LOCKWASHER, PLATE BOLT	2		
29	11	17172	NUT, PLATE BOLT	2		
30	87	17171	STOP SWITCH	1		
31	84	17162	HARNESS (5.9M)	1		
32	25	16226	GROMMET, STOP SWITCH H	1		
33	10	17174	BOLT, STOP SWITCH CLAMP	1		
34	12	16080	WASHER, STOP SWITCH CL	1		
35	54	17169	CLAMP, STOP SWITCH	1		
36	11	16081	NUT, STOP SWITCH CLAMP	1		