

					Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote	
1		16840A 2	REMOTE CONTROL ATTACHING KIT	1			
2		16848	LEVER, THROTTLE WIRE	1			
3		17034	THROTTLE WIRE	1			
4	10	16223	BOLT, THROTTLE WIRE LEV	1			
5	13	16819	LOCKWASHER, THROTTLE W	1			
6	12	16224	WASHER, THROTTLE WIRE	1			
7	23	16849	COLLAR, THROTTLE WIRE LI	1			
8	84	17035	HARNESS (DUEL STOP SWIT	1			
9	17	17031	LOCK PIN	1			
10	17	17033	PIN, LOCK PIN	1			
11	24	17032	SPRING, LOCK PIN	1			
12		17030	SLEEVE	1			
13	12	17029	WASHER, CAP SPRING	2			
14		16847	THROTTLE LEVER	1			
15		17026	BRACKET	1			
16		17027	CAP, BRACKET	1			
17	24	17028	SPRING, BRACKET CAP	1			
18	13	16221	LOCKWASHER, THROTTLE L	1			
19	26	16219	SEAL, THROTTLE LEVER	1			
20	23	16220	BUSHING, THROTTLE LEVEF	1			
21		17023	BRACKET	1			
22	10	16832	BOLT, BRACKET	2			
23	13	16819	LOCKWASHER, BRACKET BO	2			
24	11	16825	NUT, BRACKET BOLT	2			
25		17024	STEERING HOOK PLATE	1			
26	10	17022	BOLT, PLATE	2			
27	12	16192	WASHER, PLATE BOLT	2			
28	13	17025	LOCKWASHER, PLATE BOLT	2			
29	11	17172	NUT, PLATE BOLT	2			
30	87	17171	STOP SWITCH	1			
31	84	17162	HARNESS (5.9M)	1			
32	25	16226	GROMMET, STOP SWITCH H	1			
33	10	17174	BOLT, STOP SWITCH CLAMP	1			
34	12	16080	WASHER, STOP SWITCH CLA	1			
35	54	17169	CLAMP, STOP SWITCH	1			
36	11	16081	NUT, STOP SWITCH CLAMP	1			

