



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		812632	STARTER HOUSING	1		
2	244	812645	SPRING SET	1		
3		812633	STARTER SHEEVE	1		
4	24	812634	RETURN SPRING	2		
5		812635	RATCHET	2		
6	24	812636	FRICTION SPRING	1		
7	10	812637	BOLT, STARTER SHAFT	1		
8		812638	FRICTION PLATE	1		
9		812642	STARTER PULLEY	1		
10	10	16828	BOLT	3		
11	13	16818	LOCKWASHER	3		
12	262	812644	FLYWHEEL	1		
13		16110	PLATE, STARTER	1		
14	50	812639	STARTER ROPE	1		
15		812640	STARTER HANDLE	1		
16	25	812641	"O" RING	1		
17		17634	STARTER LOCK	1		
18	23	17637	COLLAR, STARTER LOCK	1		
19	24	17638	SPRING, STARTER LOCK	1		
20	12	16335	WASHER, STARTER LOCK SCRE	1		
21	10	17635	SCREW, STARTER LOCK	1		
22		812643	CAM, STARTER LOCK	1		
23		17643	ROD SNAP	1		
24	13	17641	WAVE WASHER, SHOULDER SC	1		
25	10	17640	SHOULDER SCREW, CAM	1		