



Parts List

| Ref | Class | Part | Description | Qty | Comment | Footnote |
|-----|-------|----------|------------------------------|-----|----------------------------|----------|
| 1 | 1471 | 7324A 1 | SWIVEL BRACKET ASSEMBLY | 1 | | |
| 2 | 22 | 74036 | GREASE FITTING - SWIVEL BR. | 3 | | |
| 3 | 23 | 64028 | BUSHING, SWIVEL BRACKET | 2 | | |
| 4 | | 77334 | DISC, CO-PILOT | 1 | | |
| 5 | 10 | 78038 | SCREW, CO-PILOT DISC TO SAD | 3 | | |
| 6 | | 72845A 1 | PLATE ASSEMBLY, CLAMP - CO-F | 1 | | |
| 7 | | 20203 | DISC, FRICTION | 4 | CLAMP PLATE AND SWIVEL BR. | |
| 8 | 10 | 36154 | SCREW, CLAMP PLATE ADJUSTI | 1 | | |
| 9 | 12 | 35462 | WASHER, CLAMP PLATE ADJUS | 1 | | |
| 10 | 17 | 25319 | ROLL PIN, SPRING GUIDE | 1 | | |
| 11 | | 87984 1 | LEVER ASSEMBLY, TILT STOP (S | 1 | | |
| 11 | | 87984A 1 | LEVER ASSEMBLY, TILT STOP | 1 | | |
| 12 | 10 | 41433 | SCREW, TILT STOP LEVER | 2 | | |
| 13 | 13 | 31030 | WASHER, WAVE - LEVER ANCHC | 1 | | |
| 14 | 11 | 35888 | NUT, TILT STOP LEVER SCREW | 2 | | |
| 15 | | 72794 | STOP, REVERSE LOCK | 1 | | |
| 16 | 10 | 71056 | SCREW, REVERSE STOP TO SW | 1 | | |
| 17 | 13 | 26992 | LOCKWASHER, REVERSE STOP | 1 | | |
| 18 | 12 | 71055 | WASHER, REVERSE STOP SCRE | 1 | | |
| 19 | | 63554 | GUIDE, SPRING | 1 | | |
| 20 | | 79744 | LEVER, CONTROL - TROLL BRAC | 1 | | |
| 21 | 13 | 63631 | WAVE WASHER - TROLL BRACK | 1 | | |
| 22 | | 71419 | ROD, REVERSE LOCK TO SWITC | 1 | | |
| 23 | 23 | 26841 | BUSHING, NYLON - REVERSE LC | 2 | | |
| 24 | 18 | 45882 | COTTER PIN, REVERSE LOCK LE | 1 | | |
| 25 | | 63628 | LEVER, REVERSE LOCK | 1 | | |
| 26 | | 61007 | RETAINER, ROD - REVERSE LOC | 1 | | |
| 27 | | 63559 | BRACKET, TROLL | 1 | | |
| 28 | 24 | 63630 | SPRING, EXTENSION - TROLL BF | 1 | | |
| 29 | | 66559 | TUBE, SWIVEL BRACKET TO SAI | 1 | | |