



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	191	7668A 2	TOP COWL ASSEMBLY	1		
2		39538	STRIP, SOUND SEAL-REAR	1		
3		39537	STRIP, SOUND SEAL-FORWARD	1		
4		66018	MOUNT, RUBBER-TOP COWL	2		
5		89096	COVER, TRIM-TOP COWL	1		
6	10	64652	SCREW, TRIM COVER TO TOP C	1		
7	14	20165	TAB WASHER, SHEAVE SHAFT	1		
8	11	20166	NUT, SHEAVE SHAFT (LEFT HAN	1		
9		64601	COVER, VENT-TOP COWL	1		
10	10	35519	SCREW, VENT SCREEN TO TOP	2		
11		39257	BRACKET, PORT-TOP COWL FAC	1		
12		39258	BRACKET, STARBOARD-TOP CO	1		
13	10	39514	SCREW, BRACKET TO TOP COWL	4		
14	12	39143	WASHER, BRACKET SCREW (1/4	4		
15		20155	RETAINER, STARTER SPRING	1		
16	24	29340A 1	SPRING ASSEMBLY, STARTER F	1		
17	23	28912	BUSHING, SPRING GUIDE	1		
18	50	93696A 2	STARTER SHEAVE ASSEMBLY	1		
19	17	22896	PIN, RETAINER, STARTER CAE	1		
20		30596	PAWL, STARTER	3		
21	13	36206	WASHER, WAVE-STARTER PAW	3		
22	23	28919	BUSHING, NYLON-SHEAVE SHAF	1		
23	23	61005	SPACER, SHEAVE SHAFT	1		
24		26179	RETAINER, SHEAVE SHAFT TO	1		
25	12	35559	WASHER, SHEAVE SHAFT RETA	1		
26	13	20160	WASHER, WAVE-RETAINER TEN	1		
27		30595	PLATE, RETAINER-STARTER PA	1		
28		35558	SHEAVE SHAFT	1		
29		93695	PULLEY, STARTER CABLE	1		
30	23	30977	SPACER, CALBE PULLEY	1		
31	12	22887	WASHER, PULLEY FASTENING	1		
32	10	28789	SCREW, PULLEY TO TOP COWL	1		
33	50	12066A 9	STARTER CABLE ASSEMBLY	1		
		79470A 1	HANDEL AND RETAINER ASSEM	1		