



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1341	8740A 1	CARBURETOR ASSEMBLY, COM	1	
2	1395	8983	FLOAT ASSEMBLY	1	
3			PIN, FLOAT LEVER PINION	2	9
4			LEVER, FLOAT (LOWER)	1	9
5			LEVER, FLOAT (UPPER)	1	9
6	1395	8318	INLET NEEDLE, SEAT AND GA	1	9
7			GASKET, INLET SEAT	1	1,9
8			GASKET, FLOAT BOWL COVER	1	1,9
9	1399	1133	COVER, FLOAT BOWL	1	
10	10	52195	SCREW, FLOAD BOWL COVER	1	
11	10	52196	SCREW, FLOAD BOWL COVER	1	
13			GASKET, STRAINER COVER (L	1	1,9
14	1399	3938	SCREEN, FILTER	1	9
15			GASKET, STRAINER COVER (S	1	1,9
16	1399	1135	COVER, STRAINER (90 DEGRE	1	
17			GASKET, STRAINER COVER SC	1	1,9
18	10	25822	SCREW, STRAINER COVER	1	9
19	10	20847	SCREW, THROTTLE STOP LEV	1	9
20	1399	97	LEVER, THROTTLE STOP	1	
21	1399	1716	THROTTLE SHAFT	1	
22			IDLE TUBE	1	9
23			GASKET, IDLE TUBE	1	1,9
24			SCREW AND LOCKWASHER, T	1	9
25	1399	3739	THROTTLE SHUTTER	1	
26			WELCH PLUG, BODY CHANNEL	1	9
27			SPRING, THROTTLE SHAFT RE	1	9
28			SCREW, PLUG - BODY CHANNE	1	9
30			SCREW, PLUG - MAIN NOZZLE	1	9
31	1399	1896	JET, MAIN FUEL (.041)	OPT	6
31	1399	2407	JET, MAIN FUEL (.039)	OPT	6
31	1399	3026	JET, MAIN FUEL (.036)	OPT	6
31	1399	3251	JET, MAIN FUEL (.034) - STAND	1	
31	1399	3252	JET, MAIN FUEL (.032)	OPT	6
33			GASKET, JET CHANNEL PLUG	1	1,9
34			SCREW, PLUG - MAIN FUEL JE	1	9
35	1399	3740	SCREW, IDLE ADJUSTMENT	1	9
36			SPRING, IDLE ADJUSMENT SC	1	9
37	027	63309	GASKET, CARBURETOR TO REE	1	1,9
38	12	20583	WASHER, CARBURETOR MOUN	1	
39	11	24652	NUT, CARBURETOR MOUNTING	2	
	1399	1717	GASKET AND PACKING SET		