



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1341	3711	CARBURETOR ASSEMBLY, COM	1		
2	1399	110A 1	FLOAT ASSEMBLY	1		
3			PIN, FLOAT LEVER PINION	2		3
4			LEVER, FLOAT (LOWER)	1		3
5			LEVER, FLOAT (UPPER)	1		3
6	1399	1138	INLET NEEDLE, SEAT AND GA	1		3
7			GASKET, INLET SEAT	1		3,0
8			GASKET, FLOAT BOWL COVER	1		3,0
9	1399	1133	COVER, FLOAT BOWL	1		
10	10	52195	SCREW, FLOAD BOWL COVER	1		
11	10	52196	SCREW, FLOAD BOWL COVER	1		
12	13	26995	LOCKWASHER, FLOAD BOWL C	2		
13			GASKET, STRAINER COVER (L	1		3,0
14	1399	3938	SCREEN, FILTER	1		3
15			GASKET, STRAINER COVER (S	1		3,0
16	1399	1135	COVER, STRAINER	1		
17			GASKET, STRAINER COVER SC	1		3,0
18	10	25822	SCREW, STRAINER COVER	1		3
19	10	20847	SCREW, THROTTLE STOP LEV	1		3
20	1399	97	LEVER, THROTTLE STOP	1		
21	1399	1716	SHAFT, THROTTLE	1		
22			TUBE, IDLE	1		3
23			GASKET, IDLE TUBE	1		3,0
24			SCREW AND LOCKWASHER, T	1		3
25	1399	3739	SHUTTER, THROTTLE	1		
26			WELCH PLUG, BODY CHANNEL	1		3
27			SPRING, THROTTLE SHAFT RE	1		3
28	10	28845	SCREW, PLUG - BODY CHANNE	1		
29			MAIN NOZZLE	1		3
30	10	23178	SCREW, PLUG - MAIN NOZZLE	1		
31	1399	1896	JET, MAIN FUEL (.041)	OPT.		
31	1399	2407	JET, MAIN FUEL (.039)	OPT.		
31	1399	3026	JET, MAIN FUEL (.036) - STAND	1		3
31	1399	3251	JET, MAIN FUEL (.034)	OPT.		
31	1399	3252	JET, MAIN FUEL (.032)	OPT.		
32			GASKET, MAIN FUEL JET	1		3,0
33			GASKET, JET CHANNEL PLUG	1		3,0
34	10	28405	SCREW, PLUG - MAIN FUEL JE	1		
35	1399	3740	SCREW, IDLE ADJUSTMENT	1		3
36			SPRING, IDLE ADJUSTMENT S	1		3
	1399	1717	GASKET AND PACKING SET	1		2