



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		NLA	BOTTOM COWL	1		
2	19	35827	PLUG 39	1		
3	53	55891	FASTENER 39	1		
4		36187A 1	LEVER (PORT)	1		
5		36188A 1	LEVER (STARBOARD)	1		
6	23	26819	BUSHING (NYLON)	4		
7	23	31293	BUSHING (RUBBER)	2		
8		NLA	WASHER (39)	2	SERIAL 01738941-01865632	
9	53	55891	FASTENER	2		
10	17	29077	ROLL PIN (39)(40)	2	SERIAL 00000000-03028360	
10	17	58997	ROLL PIN (40)	2	SERIAL 03028361-09999999	
11	10	79953	SCREW	1		
12	12	19183	WASHER	1		
13	27	31557	GASKET (39)	1	SERIAL 00000000-02098036	1
13	27	89937	GASKET (39)(40)	1	SERIAL 02098037-09999999	0
14	27	30801	GASKET (39)(40)	1	SERIAL 00000000-03028360	0,1
14	27	55847	GASKET (40)	1	SERIAL 03028361-09999999	0
15		55936	COVER	1		
16	10	69079	SCREW	9		
17		56712	TELL TALE NOZZLE 40	1	SERIAL 03028361-09999999	
18	10	35519	SCREW	1	SERIAL 03028361-09999999	
19	32	99127109	HOSE	1	SERIAL 03028361-09999999	

