



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1341	3711	CARBURETOR ASSEMBLY, COM	1	
2	1399	110A 1	FLOAT ASSEMBLY	1	
3			PIN, FLOAT LEVER PINION	2	3
4			LEVER, FLOAT (LOWER)	1	3
5			LEVER, FLOAT (UPPER)	1	3
6	1399	1138	INLET NEEDLE, SEAT AND GAS	1	3
7			GASKET, INLET SEAT	1	3,0
8			GASKET, FLOAT BOWL COVER	1	3,0
9	1399	1133	COVER, FLOAT BOWL	1	
10	10	52195	SCREW, FLOAD BOWL COVER	1	
11	10	52196	SCREW, FLOAD BOWL COVER	1	
12	13	26995	LOCKWASHER, FLOAD BOWL C	2	
13			GASKET, STRAINER COVER (L	1	3,0
14	1399	3938	SCREEN, FILTER	1	3
15			GASKET, STRAINER COVER (S	1	3,0
16	1399	1135	COVER, STRAINER	1	
17			GASKET, STRAINER COVER SC	1	3,0
18	10	25822	SCREW, STRAINER COVER	1	3
19	10	20847	SCREW, THROTTLE STOP LEV	1	3
20	1399	97	LEVER, THROTTLE STOP	1	
21	1399	1716	SHAFT, THROTTLE	1	
22			TUBE, IDLE	1	3
23			GASKET, IDLE TUBE	1	3,0
24			SCREW AND LOCKWASHER, T	1	3
25	1399	3739	SHUTTER, THROTTLE	1	
26			WELCH PLUG, BODY CHANNEL	1	3
27			SPRING, THROTTLE SHAFT RE	1	3
28	10	28845	SCREW, PLUG - BODY CHANNE	1	
29			MAIN NOZZLE	1	3
30	10	23178	SCREW, PLUG - MAIN NOZZLE	1	
31	1399	1896	JET, MAIN FUEL (.041)	OPT.	
31	1399	2407	JET, MAIN FUEL (.039)	OPT.	
31	1399	3026	JET, MAIN FUEL (.036) - STAND	1	3
31	1399	3251	JET, MAIN FUEL (.034)	OPT.	
31	1399	3252	JET, MAIN FUEL (.032)	OPT.	
32			GASKET, MAIN FUEL JET	1	3,0
33			GASKET, JET CHANNEL PLUG	1	3,0
34	10	28405	SCREW, PLUG - MAIN FUEL JE	1	
35	1399	3740	SCREW, IDLE ADJUSTMENT	1	3
36			SPRING, IDLE ADJUSTMENT S	1	3
	1399	1717	GASKET AND PACKING SET	1	2