



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	187	4709	BOTTOM COWL	1	UNITED STATES 3764824 AND I	
1	187	5292	BOTTOM COWL	1	UNITED STATES 3529446 THRL	
2		36187A	LEVER ASSEMBLY, CLAMPING -I	1		
3		36188A	LEVER ASSEMBLY, CLAMPING -:	1		
4	53	55891	FASTENER, CLAMPING LEVER	2		
5	84	60871A	GROUND STRAP ASSEMBLY	1	UNITED STATES 3529445 AND I	
6	24	63399	SPRING, GROUND STRAP	1	UNITED STATES 3529445 AND I	
7	23	26819	BUSHING, NYLON - CLAMPING LI	4		
8	23	31293	BUSHING, RUBBER - CLAMPING	2		
9	17	58997	PIN, ROLL - CLAMPING LEVER	2		
10	10	28634	SCREW, BOTTOM COWL FLUSHI	1		
11	12	20260	WASHER, BOTTOM COWL FLUSI	1		
12		56712	NOZZLE, TELL TALE	1		
13	10	35519	SCREW, TELL TALE NOZZLE TO	1		
14	32	34395A	TUBE, TELL TALE (7 1/4")	1		
15	22	25885	ELBOW, TELL TALE - HOSE TO C	1		
16	27	45748	GASKET, POWERHEAD TO BOT1	1		2,4
17	27	55847	GASKET, EXHAUST RELEIF COVI	1		2,4
18		55936	COVER, EXHAUST RELIEF	1		
19	10	31206	SCREW, EXHAUST RELEIF COVE	9		