



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1580	6673A 2	DRIVE SHAFT HOUSING ASSEM	1		
2	16	68927	STUD, DRIVE SHAFAT HOUSIN	1		
2	16	75321	STUD, DRIVE SHAFT HOUSING	1		
3	10	79953	SCREW, GREASE FILTER	1		
4	12	20260	WASHER, GREAST FILLER SCF	1		
5	32	68979	WATER TUBE (SHORT SHAFT)	1		
5	32	75308	WATER TUBE (LONG SHAFT)	1		
6	26	36556	SEAL, WATER TUBE	1		5
7	23	86214	SPACER, WATER TUBE SEAL	1		
8	54	79791	CLAMP, CO-PILOT	1		
9		74480	MOUNT, RUBBER (TOP)	1	UNITED STATES 5805430 AND	
9		74481	MOUNT, RUBBER (BOTTOM)	1	UNITED STATES 5805430 AND	
9		88669	MOUNT, RUBBER (TOP AND BOT	2	UNITED STATES 5805431 AND I	
10	23	74308	BUSHING, RUBBER MOUNT	2		
11		68990A 1	BRACKET ASSEMBLY, STEERING	1		
12	10	75840	SCREW, STEERING ARM BRAC	4		
13	11	35814	NUT, GEAR HOUSING STUD	1		
--		75311	ADAPTOR, DRIVE SHAFT HOUSI	1		
--		94909	BEARING BLOCK, DRIVE SHAFT	1		
--	10	26668	SCREW, ADAPTOR - LONG SHAI	2		