



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
	1643	7406A34	GEAR HOUSING ASSEMBLY (SHI)	1		
	1643	7406A35	GEAR HOUSING ASSEMBLY (LOP)	1		
	1643	7406A43	GEAR HOUSING ASSEMBLY (X-LI)	1		
1	1643	7406A16	GEAR HOUSING ASSEMBLY	1		
2	22	85822A 1	CONNECTOR ASSEMBLY, SP	1		
3	17	85500	DOWEL PIN - GEAR HOUSING	2		
4	16	33778	STUD, WATER PUMP/BASE (3		
5	16	57933	STUD, GEAR HOUSING	2		
5	16	96126	STUD, GEAR HOUSING (X-LO)	2		
6	31	62091	ROLLER BEARING - DRIVE SH	1		
7		72849A 1	SCREEN ASSEMBLY, WATER	1		
8	10	36070	SCREW	1	WATER INTAKE SCREEN TO GE	
9	11	45812	NUT, WATER INTAKE SCREE	1		
10		92815	PLATE, SUPPORT - EXHAUST	1		
11		37721	SEAL, EXHAUST TUBE	1		
12	43	98097	PINION GEAR - DRIVE SHAFT	1		
13	11	55910	NUT, PINION GEAR TO DRIVE :	1		
14	27	77417	GASKET, WATER PUMP BASE	1		1
15	25	26722	"O" RING, WATER PUMP BASE	1		1
16	46	77177A 1	WATER PUMP BASE ASSEMBL	1		
17	26	79831	OIL SEAL, WATER PUMP BAS	1		
18	26	90562	OIL SEAL, WATER PUMP BAS	1		
19	17	35973	DOWEL PIN, WATER PUMP E	2		
20	27	32769	GASKET, LOWER - WATER PUI	1		1
21		54705	FACE PLATE - WATER PUMP B.	1		
22	27	32770	GASKET, UPPER - FACE PLATE	1		1
23	47	89983	IMPELLER, WATER PUMP	1		
24	28	56662	KEY, IMPELLER DRIVE	1		
25	46	77822A 1	WATER PUMP BODY ASSEMBL	1		
26		48753	INSERT, WATER PUMP BOD	1		
27	26	38452	SEAL, RUBBER - WATER INLU	1		1
28	12	38453	WASHER, NYLON - WATER F	1		
29	12	29245	WASHER, WATER PUMP BODY	3		
30	11	35888	NUT, WATER PUMP BODY ANI	3		
31	25	20273	RING, RUBBER - CENTRIFUGAI	1		1
32		88868A 1	SEAT ASSEMBLY, DRIVE SHAF	1		
33		86304	SEAL, SPLINED - DRIVE SHAF	1		1
34	10	79953	SCREW, GREASE FILLER	1		
35	22	67892	SCREW, DRAIN - MAGNETIC	1		
36	12	20260	WASHER, FILLER/DRAIN SCRE	2		
37		88181	SLEEVE, LUBRICATION - DRIVE	1		