



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	454	7516A 1	CRANKSHAFT ASSEMBLY	1	
2		78308A 1	RETAINER ASSEMBLY, BALL B	1	
3		63742	BALL BEARING, RETAINER (C	1	
4	53	63634	RETAINING RING, BALL BEARII	1	
5	540	7238A 2	MAIN BEARING ASSEMBLY, VAL	1	
6	17	20032	DOWEL PIN, MAIN BEARING	2	
7	10	45775	SCREW, MAIN BEARING CLAMI	2	
8	11	45774	NUT, MAIN BEARING CLAMPIN	2	
9	34	56007A 1	REED SET, MAIN BEARING (MA	1	
10	34	56008	REED STOP, MAIN BEARING R	4	
11	10	20055	SCREW, REED STOP MOUNTIN	12	
12	624	8101A 3	CONNECTING ROD ASSEMBLY	2	
13	10	54803	SCREW, CONNECTING ROD - \	4	
14	11	49091	NUT, CONNECTING ROD SCRE	4	
15	10	91012	SCREW, CONNECTING ROD - \	4	
16	31	62596A 1	BEARING ASSEMBLY, CRANKP	2	
17	29	47270	NEEDLE BEARING - PISTON PII	58	
18	12	47247	WASHER, NEEDLE BEARING R	4	
19	745	7672A 3	PISTON AND PISTON PIN ASSEM	2	
20	745	7673A 2	PISTON AND PISTON PIN ASSEM	AR	3
21	745	7674A 2	PISTON AND PISTON PIN ASSEM	AR	3
22	40	52035	LOCK RING, PISTON PIN	4	
23	39	78816A12	PISTON RING	1	
24	39	78811A12	PISTON RING (.015 OVERSIZE)	AR	3
25	39	88392A12	PISTON RING (.030 OVERSIZE)	AR	3
26	28	45554	KEY, CRANKSHAFT	1	