



| Parts List | | | | | | |
|------------|-------|----------|-------------------------------|-----|-----------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 62351A 1 | RECTIFIER ASSEMBLY | 1 | | |
| 2 | 10 | 20646 | SCREW | 2 | RECTIFIER TO FRONT SUPPOR | |
| 3 | 11 | 27164 | NUT, RECTIFIER FASTENING SC | 2 | | |
| 4 | 11 | 45076 | NUT, RECTIFIER TERMINAL (10-) | 3 | | |
| 5 | | 54293A 5 | CHOKE SOLENOID ASSEMBLY | 1 | | |
| 6 | 10 | 25299 | SCREW | 2 | CHOKE SOLENOID FRONT SUPI | |
| 7 | 13 | 26996 | LOCKWASHER, CHOKE SOLEND | 1 | | |
| 8 | 11 | 45076 | NUT, CHOKE SOLENOID TERMIN | 1 | | |
| 9 | | 89008A 2 | PLUNGER ASSEMBLY, CHOKE SI | 1 | | |
| 10 | 19 | 35827 | PLUG, BOTTOM COWL | 1 | PART OF BOTTOM COWL ASSE | |
| 11 | 11 | 30428 | FASTENER, PLUG TO BOTTOM C | 1 | PART OF BOTTOM COWL ASSE | |
| 12 | 84 | 88644A 1 | WIRING HARNESS | 1 | UNITED STATES 5823917 AND I | |
| 12 | 84 | 93948A 1 | WIRING HARNESS | 1 | UNITED STATES 5823918 THRL | |
| 12 | 84 | 96219A 2 | WIRING HARNESS | 1 | UNITED STATES 6052943 AND I | |
| 13 | 88 | 79091 | FUSE | 1 | UNITED STATES 6052943 AND I | |
| 14 | 88 | 95084A 2 | WIRE ASSEMBLY, FUSE | 1 | UNITED STATES 6052943 AND I | |
| 15 | 54 | 88167 | CLAMP, WIRING HARNESS | 1 | UNITED STATES 6052943 AND I | |
| 16 | 10 | 23702 | SCREW, WIRING HARNESS CLAI | 1 | | |
| 17 | 24 | 28357 | SPRING, WIRING HARNESS CLA | 1 | | |
| 18 | 12 | 72761 | WASHER, WIRING HARNESS CL | 1 | | |
| 19 | 84 | 88439A 3 | BATTERY CABLE ASSEMBLY (PO | 1 | | |
| 19 | 84 | 88439A 4 | BATTERY CABLE ASSEMBLY (NE | 1 | | |
| 20 | | 88620 | BRACKET, HARNESS SUPPORT | 1 | | |
| 21 | 10 | 73280 | SCREW, HARNESS SUPPORT BF | 2 | | |
| 22 | | 88617 | COVER, HARNESS SUPPORT BR | 1 | | |
| 23 | 10 | 28635 | SCREW, HARNESS SUPPORT BF | 2 | | |
| 24 | 50 | 55601A 2 | STARTER MOTOR ASSEMBLY (9 | 1 | | |
| 24 | 50 | 41583 | STARTER MOTOR ASSEMBLY (1 | 1 | | |
| 25 | 10 | 35213 | SCREW, STARTER MOTOR TO C | 2 | | |
| 26 | 27 | 86663 | GASKET, STARTER MOTOR | 1 | | |
| 27 | 13 | 26992 | LOCKWASHER, CABLE TO STAR | 1 | | |
| 28 | 11 | 20890 | NUT, CABLE TO STARTER MOTC | 1 | | |
| 29 | 84 | 93389A 3 | CABLE, STARTER TO SOLENOID | 1 | UNITED STATES 5823917 AND I | |
| 29 | 84 | 88809A 6 | CABLE, STARTER TO SOLENOID | 1 | UNITED STATES 5823918 AND I | |
| 30 | 10 | 69035 | SCREW | 1 | BATTERY CABLE TO STARTER | |
| 31 | 89 | 76545 | STARTER SOLENOID | 1 | UNITED STATES 5823917 AND I | |
| 32 | 10 | 98253 | SCREW, SOLENOID TO BRACKE | 2 | UNITED STATES 5823917 AND I | |
| 33 | 13 | 26992 | WASHER, STARTER SOLENOID | 2 | UNITED STATES 5823917 AND I | |
| 34 | 85 | 78866 | INSULATOR, STARTER SOLEND | 1 | UNITED STATES 5823917 AND I | |
| 35 | 13 | 26996 | LOCKWASHER, TERMINAL (#10) | 2 | UNITED STATES 5823917 AND I | |
| 36 | 11 | 68219 | NUT, STARTER SOLENOID TERP | 2 | UNITED STATES 5823917 AND I | |