



Loctite PST Pipe Sealant (92-809822)

A= To carburetor  
 B= to crankcase  
 C = TO TOP CARB  
 D= TO MANIFOLD TOP  
 E= TO MANIFOLD BOTTOM

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		14360A43	FUEL PUMP ASSEMBLY	1		
1		NSS	FUEL PUMP	1		4
2	21	42990A10	DIAPHRAGM KIT	2		1
3		NSS	DIAPHRAGM KIT	1		4,7
4		NSS	RUBBER CHECK VALVE	2		4,7
5		NSS	RETAINER	2		4,7
6		NSS	SPRING	1		4,7
7		NSS	CAP	1		4,7
8		NSS	SPRING	1		4,7
9		NSS	CAP	1		4,7
10		NSS	DIAPHRAGM	1		4,7
11	27	98769 1	GASKET	1		2,7
12		NSS	GASKET-BOOST	1		4,7
13		NSS	GASKET-PULSE	1		4,7
14		98775 2	PLATE	1		
15	22	43335	FITTING	2		2
16	10	821045 40	SCREW-FUEL PUMP (M5 X 40)	2		
16	10	821300 50	SCREW-PUMP TO CRANKCASE	2		
17		14430 3	BASE	1		
18	32	830757 80	HOSE (22 IN.)	1		
19	54	816311	STA-STRAP	AR		10
20	32	830761	HOSE	1		
21	32	99128 78	HOSE (4-1/4 IN.)	1		
22	35	816296 1	FUEL FILTER	1		
23	32	831949	HOSE	1		
24	22	59169	TEE FITTING	1		
25	32	99130122	HOSE (9-1/2 IN.)	2		
26		816877 3	PRIMER BULB	1		
27	22	816856A 1	FUEL CONNECTOR	1		
28	10	40003 32	SCREW (M6 X 35)	1		
29	32	99130122	HOSE (5-1/2 IN.)	1		
30	32	99130122	HOSE (1-1/2 IN.)	1		
-		852067A98	POWERHEAD	1		3
-	27	828553A97	GASKET SET	1		