



| Parts List | | | | | | |
|------------|-------|----------|-------------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| - | 87 | 18286A18 | SWITCH KIT, Trim (10.00 Feet) | 1 | | |
| 1 | | 18861 | RETAINER | 1 | | |
| 2 | | 814820 | ADAPTOR | 1 | | |
| 3 | | NSS | NOT SOLD SEPARATE, Switch | 1 | | |
| 4 | 88 | 79091 | FUSE, 20 Ampere | 1 | | |
| 5 | 84 | 95084A 2 | CABLE ASSEMBLY | 1 | | |
| 6 | 84 | 11149A 2 | CABLE ASSEMBLY, (6.00 Inches | 2 | | |
| 7 | 10 | 19209 | SCREW, (#10-32 x 2.25) | 2 | | |
| 7 | 10 | 813523 | SCREW, (#10-16 x 2.25) | 2 | | |