



Loctite PST Pipe Sealant (92-809822)

A= To carburetor  
 B= to crankcase  
 C = TO TOP CARB  
 D= TO MANIFOLD TOP  
 E= TO MANIFOLD BOTTOM

Parts List					
Ref	Class	Part	Description	Qty	Footnote
-		14360A43	FUEL PUMP ASSEMBLY	1	
1		NSS	FUEL PUMP	1	4
2	21	42990A10	DIAPHRAGM KIT	2	1
3		NSS	DIAPHRAGM KIT	1	4,7
4		NSS	RUBBER CHECK VALVE	2	4,7
5		NSS	RETAINER	2	4,7
6		NSS	SPRING	1	4,7
7		NSS	CAP	1	4,7
8		NSS	SPRING	1	4,7
9		NSS	CAP	1	4,7
10		NSS	DIAPHRAGM	1	4,7
11	27	98769 1	GASKET	1	2,7
12		NSS	GASKET-BOOST	1	4,7
13		NSS	GASKET-PULSE	1	4,7
14		98775 2	PLATE	1	
15	22	43335	FITTING	2	2
16	10	821045 40	SCREW-FUEL PUMP (M5 X 40)	2	
16	10	821300 50	SCREW-PUMP TO CRANKCASE	2	
17		14430 3	BASE	1	
18	32	830757 80	HOSE (22 IN.)	1	
19	54	816311	STA-STRAP	AR	10
20	32	830761	HOSE	1	
21	32	99128 78	HOSE (4-1/4 IN.)	1	
22	35	816296 1	FUEL FILTER	1	
23	32	831949	HOSE	1	
24	22	59169	TEE FITTING	1	
25	32	99130122	HOSE (9-1/2 IN.)	2	
26		816877 3	PRIMER BULB	1	
27	22	816856A 1	FUEL CONNECTOR	1	
28	10	40003 32	SCREW (M6 X 35)	1	
29	32	99130122	HOSE (5-1/2 IN.)	1	
30	32	99130122	HOSE (1-1/2 IN.)	1	
-		852067A98	POWERHEAD	1	3
-	27	828553A97	GASKET SET	1	