



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		19106	COVER-ELECTRICAL BOX	1		
2	10	41805	SCREW-MERCURY SWITCH AND	6		
3	10	19639	SCREW-COVER AND BOX TO EN	3		
4	88	812619	FUSE	2	ELECTRIC	
5		816770	RECTIFIER	1	ELECTRIC	
6	10	41805	SCREW-RECTIFIER	2	ELECTRIC	
7	11	45076	NUT-RECTIFIER TERMINAL	3	ELECTRIC	
8	89	96054	STARTER SOLENOID	1	ELECTRIC	
9	10	41508	SCREW-SOLENOID	2	ELECTRIC	
10	13	26992	WASHER-STARTER SOLENOID	2	ELECTRIC	
11	11	26419	LOCK-SOLENOID TERMINAL (#8-3	2	ELECTRIC	
12	13	26992	NUT-WASHER-SOLENOID TERM	2	ELECTRIC	
13	11	64015	NUT-SOLENOID TERMINAL (1/4-	2	ELECTRIC	
14	84	18672A 2	WIRING HARNESS (USE WITH R	1	ELECTRIC	
14	84	18672A 6	HARNESS (GRAY LEAD HAS RIN	1	ELECTRIC	
14	84	18672A 8	HARNESS (GRAY LEAD HAS BUL	1	ELECTRIC	
-	84	88807A14	CABLE (RING/MALE CONNECTO	1	ELECTRIC	
-	84	88807A15	CABLE (RING/FEMALE CONNECT	1	ELECTRIC	
15	10	812832	SCREW-WIRING HARNESS LEAC	1	ELECTRIC	
16	86	63813 1	TERMINAL BLOCK	1	MANUAL	
17	10	41805	SCREW-TERMINAL BLOCK (5/8 II	2	MANUAL	
17	10	62568	SCREW-TERMINAL BLOCK (3/8 II	2	MANUAL	
18		16731A 1	MERCURY SWITCH	1		
19	339	7370A13	IGNITION COIL ASSEMBLY	4		
20	84	60466A19	GROUND WIRE-COIL TO SWITCH	4		
21	11	45076	NUT-IGNITION COIL TERMINALS	8		
22	84	813715A12	LEAD ASSEMBLY-SPARK PLUG	1		
23	85	63709A 1	PROTECTOR ASSEMBLY	4		
24	33	97182	SPARK PLUG	4		
24	33	14103550	SPARK PLUG	4	(BELGIUM AND CANADA)	
25	332	5772A 5	SWITCH BOX ASSEMBLY	1		
26	10	812987	SCREW-SWITCH BOX	4		
27	11	45076	NUT-SWITCH BOX TERMINALS	13		
28	84	88818A 1	CABLE (GREEN)	1		
28	84	88819A 1	CABLE (GREEN/WHITE)	1		
28	84	88820A 1	CABLE (GREEN/BLACK)	1		
28	84	88821A 1	CABLE (GREEN/RED)	1		
29	84	88807A30	CABLE (BLACK)	1	MANUAL	
30	10	812832	SCREW	1	MANUAL	
31	84	813060A 1	CABLE	1	MANUAL	
32		14957A10	OIL WARNING MODULE	1	ELECTRIC	