



Parts List					
Ref	Class	Part	Description	Qty	Footnote
-	1682	821306T54	GEAR HOUSING ASSEMBLY-COM	1	
1	1682	821306T12	GEAR HOUSING, (Basic)	1	
39	17	821327	PIN, Dowel	2	
40	27	823942	GASKET	1	
41	32	821828	TUBE	1	
42	19	824928001	PLUG, Rubber	1	
43		821829	SCREEN	1	
44		822157T 2	TRIM TAB	1	
45	10	824970 20	SCREW, (M8 x 20)	1	
46	12	72397	WASHER	1	
47	43	821315T 1	FORWARD GEAR ASSEMBLY, (1	
48	31	99328A 1	ROLLER BEARING ASSEMBL'	1	
49		NSS	NOT SOLD SEPARATE, Cup	1	
50	31	41326	ROLLER BEARING	1	
51		821578	FOLLOWER, Cam	1	
52	24	826199 1	SPRING	1	
53	17	85093	PIN	1	
54	52	821314T	CLUTCH	1	
55	24	38114	SPRING	1	
56	44	821577 2	PROPELLER SHAFT	1	
57	43	821312T 1	REVERSE GEAR, (26 Teeth)	1	
58	30	20839T	BEARING	1	
59		19291A 3	BEARING CARRIER	1	
60	25	815460	O-RING	1	15
61	31	21700	BEARING, Needle	1	
62	26	69188	OIL SEAL	1	15
63	26	69189	OIL SEAL	1	15
64	12	855941	WASHER	2	
65	10	855940 30	SCREW, (M8 x 30)	2	
66		822773 1	INSERT, Threaded	2	
67		NSS	NOT SOLD SEPARATE, Decal	2	
68		73345A 1	THRUST HUB	1	
69	11	69578Q 1	PROP NUT KIT	1	
70	14	76281	TAB WASHER	1	
71	10	40003 80	SCREW, (M10 x 45)	4	
72	12	856774	WASHER, (.406 x .750 x .105)	4	
73	19	95925	PLUG	1	
-		823547A03	GEAR HOUSING SEAL KIT	1	