



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		832991T 3	EXHAUST VALVE	3	6
2		832990T 3	INTAKE VALVE	3	6
3	26	858271	SEAL	6	6,2
4	24	858268	VALVE SPRING-OUTER	6	6
5		822650	RETAINER	6	6
6	28	822651	KEY	12	6
7		825045A 2	ROCKER ARM	6	6
8	10	825046	SCREW	6	6
9	11	826150	NUT	6	6
10		834780T 1	ROCKER SHAFT	1	6
11		NSS	NOT SOLD SEPARATE, Plug	2	6
12		859577	BRACKET	1	6
13	24	825052 1	SPRING	1	6
14		858275	BRACKET	1	6
15	24	854713	SPRING	1	6
16	27	859576	SEAL CAP	1	6
17	17	859575	PIN	1	6
18	10	875218	SCREW, (M8 x 23)	4	6
19	24	889775	SPRING, Overload	2	
-	27	825231A02	ENGINE GASKET SET	1	
-		877568T 9	CYLINDER HEAD	1	