

## Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-	92	<a href="#">802833Q</a>	1 OIL (CASE)			
-		15000A	7 KEY SWITCH KIT, Remote Ignition			
-	32	<a href="#">877680Q</a>	8 HOSE ASSEMBLY, Fuel		(8 FT. )(w/QUICK DISCONNECT)	
-	32	<a href="#">877680Q12</a>	12 HOSE ASSEMBLY, Fuel		(12 FT. )(w/ QUICK DISCONNECT)	
-	32	<a href="#">877681Q</a>	8 HOSE ASSEMBLY, Fuel		(8 FT. )(w/ QUICK DISCONNECT)	
-	32	<a href="#">877681Q12</a>	12 HOSE ASSEMBLY, Fuel		(12 FT. )(w/ QUICK DISCONNECT)	
-	32	<a href="#">877683Q12</a>	12 HOSE ASSEMBLY, Fuel		(NO FITTINGS)	
-	32	<a href="#">877680Q</a>	8 HOSE ASSEMBLY, Fuel		(SUPPLIED WITH ENGINE)	
-		859185A	2 REMOTE CONTROL ATTACHING	1		
-		828019A	1 OIL PRESSURE SENDER KIT	1		
-		821400A	2 SENDER KIT, Power Trim	1		
-		830150A	8 POWER TRIM KIT	1	SN# 0T979999 & Below	
-		830150A	8 POWER TRIM KIT	1	SN# 0P325499 & Below	
-		821455A	12 TILLER HANDLE KIT	1	(ELECTRIC START)	
-		816667A	2 STEERING BRACKET	1	(w/O CARRYING HANDLE)	
-		824072A	5 EXTENSION KIT, (22.5)	1	(Converts 20 In. to 22-1/2 In.)	
-	90	899697A01	1 DIAGRAM SET, Colored	1		

NO IMAGE