



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
24	91	63209	HEAT LAMP	1		
25	91	877321A 1	BEARING INSTALLATION TOOL	1		
26	91	13945	INSTALLATION TOOL, Bearing	1		
	91	31229A 7	PULLER KIT, Bearing	1		
27		NSS	NOT SOLD SEPARATE, Expanding	1		
28		NSS	NOT SOLD SEPARATE, Collet (P/I)	1		
29	11	24156	NUT, (.625-18)	1		
30	12	34961	WASHER	1		
31	91	29310	PLATE	1		
32	91	31229	SHAFT	1		
33	91	36571T	DRIVESHAFT BEARING WRENCH	1		
34	91	37323	DRIVER ROD	1		
35	91	15755T	MANDREL	1		
36	91	36569T	DRIVEHEAD TOOL	1		
37	91	27780	PULLER	1		
38	91	37241	PULLER PLATE	1		
39	91	37312T	DRIVER HEAD	1		
40	91	817011T	NEEDLE BEARING CARRIER INS	1		
41	84	825003A 1	DDT CABLE (10 Feet)	1		
42	91	13949	DRIVER, Oil Seal	1		
43	91	817007T	BEARING CARRIER SEAL INSTAL	1		
44	91	43506T	BEARING RETAINING TOOL	1		
45	91	817005	FORWARD GEAR BEARING INST	1		
46	91	817006	WATER PUMP BASE SEAL INST	1		
47	91	817008A 2	PINION GEAR LOCATION TOOL	1		
48	91	817009T	FORWARD GEAR BEARING RAC	1		
49	91	12349A05	TOOL, Pinion Locating	1		