



9397

			Parts List			
Ref	Class	Part	Description	Qty	Comment	Footnote
1	10	821291 25	SCREW, (M6 x 25)	3		
2		893774002	BRACKET	1		
3	12	40023 16	WASHER	3		
4	25	834985	GROMMET	3		
5		89195232T	ECM	1	(40)	
5		89195231T	ECM	1	(40 Bodensee)	
6	23	856954	BUSHING	3		
7	10	821291 14	SCREW, (M6 x 14)	1		
8		858953	BRACKET	1		
9	54	858954	CLIP, (.625)	2		
10	54	879962	CLIP (Part of Electrical Harness)	3		
11		893764001	PLATE	1		
12	10	824832 4	SCREW, (M6 x 16)	3		
13	84	883834A 1	DIODE ADAPTOR CABLE	1		
14		882753	BRACE	1		
15	10	821291 14	SCREW, (M6 x 14)	2		
16		893768	PLATE, Solenoid	1		
17	10	821291 14	SCREW, (M6 x 14)	1		
18		95643M	BRACKET	1		
19	89	825096T	RELAY	1		
20	84	93388A16	CABLE ASSEMBLY, (8.50 Inches)	1		
21	11	40138 6	NUT, (M6)	2		
22	84	88439A 9	BATTERY CABLE, Positive	1		
23	85	880786	BOOT, Insulator - Red	1		
24	84	893665T04	HARNESS ASSEMBLY, Engine	1		
25	88	832969 20	FUSE, Yellow - 20 Ampere	3	(20 AMP)	
25	88	832969 25	FUSE, Clear - 25 Ampere	1	(25 AMP)	
25	88	832969 5	FUSE, Tan - 5 Ampere	1	(5 AMP)	
26		858754	COVER, Fuse	1		
27	54	816311T	CABLE TIE, (8.00 Inches)	AR		
28		13541	PLUG, Male	1		
29		828358 2	SENSOR	1		
30	10	40011107	SCREW, (M5 x 16)	2		
31		893640T01	VOLTAGE REGULATOR	1		
32		893771	BRACKET, Connector	1		
33		830897 1	FOAM PAD	1		
34	10	824832 9	SCREW, (M6 x 40)	2		
35	87	828040 1	PRESSURE SWITCH	1		
36	50	893887T	STARTER MOTOR ASSEMBLY, C	1		
37	11	94330	NUT, (.250-20)	1		
38	84	88439A 4	BATTERY CABLE, Negative	1		