



1293

				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1667	9011G90	GEAR HOUSING ASSEMBLY, Con	1		
1	1667	9011G59	GEAR HOUSING, Basic	1		
2	31	30894A 1	BEARING SET, Cup And Cone	1		
3		NSS	NOT SOLD SEPARATE, Cup	1		
4	43	882813A 3	GEAR KIT, Forward And Pinion (2	1		
5	31	30895T	BEARING, Needle	1		
6	53	856823	RING, Retaining	1		
7		850315A 1	FOLLOWER KIT, Cam	1		
8	30	44530	BALL	3		
10		NSS	NOT SOLD SEPARATE, Slide	1		
10	24	850327	SPRING	1		
11	52	850048T	CLUTCH	1		
12	17	30632	PIN, Cross	1		
13	24	30893	SPRING	1		
14	44	850308	PROPSHAFT	1		
15	43	882814T	REVERSE GEAR, (28 Teeth)	1		
16		12596T 2	CARRIER ASSEMBLY, Bearing	1		
17	25	97386	O-RING, (3.609 x .139)	1		15
18	31	30956T	BEARING, Needle	1		
19	26	70080	SEAL, Oil (Inner)	1		15
20	26	70081	SEAL, Oil (Outer)	1		15
21	31	12578T	ROLLER BEARING	1		
22	12	12577	THRUST WASHER	1		
23	31	12576	BEARING, Thrust	1		
24	16	42917 2	STUD, (M8 x 48)	2		
25	12	855941	WASHER	2		
26	11	40137 8	NUT, (M8)	2		
27	15	44491A 1	SHIM SET	AR		
28		822773 1	INSERT, Threaded	2		
29		NSS	NOT SOLD SEPARATE, Decal	1		
30		NSS	NOT SOLD SEPARATE, Decal-Prc	1		
31		13191001	HUB, Thrust	1		
32	11	527070 1	NUT KIT, Propeller	1		
33	14	8166290	TAB WASHER	1		
34	10	40003 80	SCREW, (M10 x 45)	4		
35	12	856774	WASHER, (.406 x .750 x .105)	4		
-	26	43035A05	SEAL KIT, Gear Housing	1		