



5806

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		853811	RECTIFIER	1		23
2	10	855544	SCREW	2		23
3		853829A	CHOKE SOLENOID	1		
4		853830	PLUNGER	1		
5	10	16245	SCREW	3		
6		851836	BRACKET	1		
7	10	16223	SCREW	2		
8		855561	HOOK	1		
9	17	95218	PIN, Dowel	1		
10	84	853740	WIRING HARNESS	1		23
11	84	853740	FUSE WIRE	1		23
12	87	851839	SOLENOID SWITCH	1		
13	87	851839	SOLENOID SWITCH	1		
14	84	853740	CABLE	1		
15	84	853740	CABLE, (Black)	1		
16	84	853740	CABLE	1		
17	84	853740	CABLE	1		
18	85	853816	CAP	6		
19	10	823042	BOLT	2		
20		802808A	OVER-HEAT BUZZER	1	(40 Lightning XR/50)	
21		802809A	OVER-HEAT SENSOR	1	(40 Lightning XR/50)	
22		810753	STOPPER	1	(40 Lightning XR/50)	
23	10	823042	BOLT	1	(40 Lightning XR/50)	
24	84	853740	WIRING HARNESS (Handle)	1		23
-		804056A	ELECTRIC STARTER KIT	1		