

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	35	853733A	FUEL FILTER ASSEMBLY	2	
2		853735	CUP	1	
3	25	851815	O-RING	1	2
4	35	853733	FILTER	1	
5	25	851815	O-RING	1	2
6	11	853722	NUT	1	
7	12	16192	WASHER	2	
8	21	851812	CHECK VALVE (Oil Injection)	1	
9	32	95394013	TUBING (Oil Injection)	1	
10	32	851848011	HOSE, Fuel (Oil Injection)	1	
11	32	95394014	TUBING (Oil Injection)	1	
12	32	95394015	TUBING (Oil Injection)	2	
13	54	95395	CLIP (Oil Injection)	10	
14	22	853736	FUEL CONNECTOR	1	
15	11	17480	NUT	1	
16	54	95395	CLIP (Non-Oil Injection)	8	
17	32	851848014	TUBING (Non-Oil Injection)	1	
18	32	95394016	TUBING (Non-Oil Injection)	1	
19	27	803663017	GASKET	1	
-	27	812937A02	GASKET SET, Powerhead	1	

