



18047

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		853775	GRIP	1		
2		853776	BUTTON	1		
3		804049	REVERSE LOCK LEVER SHAFT	1		
4	12	16826	WASHER	3		
5		804048	TILT STOPPER LEVER	1		
6	12	895118002	WASHER	1		
7	24	804024	SPRING	1		
8		804050	LINK	1		
9		804046003	SHAFT, Reverse Lock	1		
10	53	16057	E RING	2		
11	24	95383	FRICTION SPRING	1		
12		853774	STOP	1		
13		825113	BRACKET	1		
14		825112006	TILT STOPPER	1		
15	17	95218	SPRING PIN	1		
16		16210	SET PLATE	1		
17	10	823042052	BOLT	2		
18	24	804024	SPRING	2	(Short)	
18	24	804024	SPRING	2	(Long)(X-Long)	
19		804047	REVERSE LOCK ROD	1		
20		804044	REVERSE LOCK (Starboard)	1		
21		804045004	ARM, Reverse Lock	1		
22		804044	REVERSE LOCK (Port)	1		
23	18	815026	COTTER PIN	1		
24		804049001	SHAFT	1		
25	24	804024009	SPRING	1		
26	24	804024010	SPRING	1		