



5812

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	474	9614A	2 CRANKSHAFT ASSEMBLY	1		5
2	30	16049	2 BEARING, Ball	1		5
3	43	855552	DRIVE GEAR	1		5
4	53	853714	C CLIP	1		5
5	41	880810	CRANK PIN	2		5
6	629	880855	CONNECTING ROD	2		5
7	31	880856	NEEDLE BEARING	2		5
8	12	880857	WASHER	4		5
9	779	9615	2 PISTON	3	(Standard)	5
9	779	9616	2 PISTON	AR	(.5 Oversize)	
10	39	16054A	5 RING SET, PISTON	3	(Standard)	5
10	39	16055A	5 RING SET, PISTON	AR	(.5 Oversize)	
11	41	16056	1 PISTON PIN	3		5
12	53	16057	1 CLIP	6		5
13		853712	THRUST RING	2		5
14	28	16053	1 KEY	1		5
15	31	855553	MAIN BEARING (Upper)	1		5
16	26	803879	OIL SEAL	1		5
17	25	855554	O-RING	1		2,5
18	31	813048	3 NEEDLE BEARING	3		5
-		851886A06	POWERHEAD ASSEMBLY	1	(40)	
-		802806A99	POWERHEAD	1	(40 Lightning XR/50)	
-		812937A02	GASKET SET, Powerhead	1		