



5767

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	2189	853778A 3	TOP COWL	1	(Black-Electric 40)	
1	2189	853778A 4	TOP COWL	1	(Silver-Electric 40)	
1	2189	853778A13	TOP COWL	1	(Black-Electric-Un-Decaled)	
1	2189	853778A14	TOP COWL	1	(Silver-Electric-Un-Decaled)	
2	2189	853778A 7	TOP COWL	1	(Black-Manual 40)	
2	2189	853778A 8	TOP COWL	1	(Silver-Manual 40)	
2	2189	853778A11	TOP COWL	1	(Black-Manual-Un-Decaled)	
2	2189	853778A12	TOP COWL	1	(Silver-Manual-Un-Decaled)	
3		851851 2	SEAL	1		
4		853779 3	COWL CAP	1	(Black-Electric)	
4		853779 4	COWL CAP	1	(Silver-Electric)	
4		853779 5	COWL CAP	1	(Black-Manual)	
4		853779 6	COWL CAP	1	(Silver Manual)	
5	11	40021 2	NUT, (M6)	4		
6	12	95392 1	WASHER	4		
7		851851 3	SEAL (Electric)	1		
8		851884	COVER-FILL	1	(Black-Electric)	
8		851884 1	COVER-FILL	1	(Silver-Electric)	
9		815105 1	HINGE (Electric)	1		
10		851885	SPRING PLATE (Electric)	1		
11	10	16223	BOLT, (M6 x 14) (Electric)	2		
12	11	40021 2	NUT, (M6) (Electric)	2		
13	25	16228 1	RUBBER SEAL (Manual)	1		