



A = TO OIL PUMP

5813

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		851840A	OIL PUMP	1		
2	25	851815	O-RING	1		
3	10	851841	BOLT	1		
4	12	95392	WASHER	1		
5	10	16263	BOLT	2		
6	13	40025	LOCKWASHER, (M6)	2		
7	43	855552	DRIVEN GEAR	1		
8	23	851858	BUSHING	1		
9		16333	ROD SNAP	1		
10		855561	LINK ROD	1		
11	11	853722	NUT	1		
12		853745	CAP	1		
13	1270	851842	OIL TANK	1		
14	25	851815	GROMMET	3		
15	23	853715	SPACER	3		
16	23	853743	MOUNT, Rubber	3		
17	10	16223	BOLT	3		
18	12	16140	WASHER	6		
19	36	851843	CAP	1		
20	27	851844	GASKET	1		
21		851845	HOOK	1		
22	21	851812	CHECK VALVE	1		
23		851846	SENSOR	1		
24	35	851847A	OIL FILTER ASSEMBLY	1		
25		853735	CUP	1		
26	25	851815	O-RING	1		
27	35	851847	FILTER	1		
28	25	851815	O-RING	1		
29	11	853722	NUT	1		
30	12	16192	WASHER	2		
31	32	851848	TUBING	1		
32	32	851848	TUBING	1		
33	54	851817	CLIP	4		
34	32	851848	TUBING	1		
35	54	851849	CLIP	2		