



18031

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		804021A 1	RECOIL STARTER	1		
2	23	851858 3	BUSHING	1		
3		804026	SLIDING PLATE	1		
4	24	804024	STARTER SPRING	1		
5		804022	REEL	1		
6	12	95392 12	WASHER	1		
7	53	804027	C RING	1		
8	24	804024 2	RETURN SPRING	1		
9		804023	RATCHET	1		
10	24	804024 1	FRICTION SPRING	1		
11		804026 1	SLIDING PLATE	1		
12		804025	FRICTION PLATE	1		
13	10	16263 7	BOLT	1		
14	50	804028	STARTER ROPE	1		
15		804029	STARTER HANDLE	1		
16		804030	GUIDE	1		
17	10	16263 7	BOLT	2		
18		804031	REEL STOPPER	1		
19		804032	STOPPER ARM	1		
20	24	804024 3	STOPPER SPRING	1		
21	12	95392 13	WASHER	1		
22	18	815026 11	COTTER PIN	1		
23	84	853740 13	WIRE	1		
24		804033	CABLE HOLDER	1		
25	10	804034	SCREW	1		
26	23	811368 3	SLEEVE	1		
27		853755002	CAP, Starter Handle	1		
28	13	40025 6	LOCKWASHER, (M6)	3		
29	10	40003 30	SCREW, (M6 x 25)	1		
30	12	16826	WASHER	2		
31	23	95286 24	COLLAR	1		
32		804036	STARTER LOCK ARM	1		
33		804035	STARTER PULLEY	1		
34	10	16830 7	BOLT	3		
35	13	17025	LOCKWASHER	3		
36	10	40003 30	SCREW, (M6 x 25)	3		