



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	35	853733A	2 FUEL FILTER ASSEMBLY	1		
2		853735	1 CUP	1		
3	25	851815	1 O-RING	1		2
4	35	853733	1 FILTER	1		
5	25	851815	1 O-RING	1		2
6	11	853722	3 NUT	1		
7	12	16192	WASHER	2		
8	21	851812	1 CHECK VALVE (Oil Injection)	1		
9	32	95394	9 FUEL LINE (Oil Injection)	1		
10	32	95394	9 FUEL LINE (Oil Injection)	1		
11	32	95394	9 FUEL LINE (Oil Injection)	1		
12	32	824965	HOSE (Oil Injection)	2		
13	54	95395	CLIP (Oil Injection)	10		
14	22	853736	FUEL CONNECTOR	1		
15	11	17480	NUT	1		
16	54	95395	CLIP (Non-Oil Injection)	8		
17	32	95394	9 FUEL LINE (Non-Oil Injection)	1		
18	32	95394	9 FUEL LINE (Non-Oil Injection)	1		
-	27	812937A98	GASKET SET, Powerhead	1	SN# 0N016161 & Below	
-	27	812937A02	GASKET SET, Powerhead	1	SN# 0N016162 & Up	