


Parts List



5807

Ref	Class	Part	Description	Qty	Comment	Footnote
1	50	853805A 3	STARTER MOTOR	1		
2		853806 1	PINION	1		
3	12	95392 6	WASHER	1		
4		853807 2	BRUSH HOLDER	1		
5	10	16821	SCREW	2		
6	23	95286 14	BUSHING	1		
7	25	16178 4	O-RING	1		
8	23	95286 19	BUSHING	1		
9	12	16826	WASHER	1		
10	13	40025 6	LOCKWASHER, (M6)	2		
11	11	40021 2	NUT, (M6)	2		
12	10	16263 2	BOLT	2		
13	13	16079	LOCKWASHER	2		
14	12	16072 1	WASHER	2		
15	89	853809	STARTER SOLENOID	1		
16	10	16223 3	SCREW	1		
17		851836 2	BRACKET	1		
18	10	16223 4	BOLT	2		
19		851838	COVER	1		
20	10	823042 9	BOLT	2		
21		851836	BRACKET	1		
22		851836 1	BRACKET	1		
23	10	823042 9	BOLT	4		
24	10	823042 6	BOLT	1		
25	10	40003 30	SCREW, (M6 x 25)	3		
26	12	95392 1	WASHER	3		
27	23	95286 13	COLLAR	3		
28	12	95392 3	WASHER, (Rubber)	3		
29		851837	RUBBER MOUNT	1		
30	84	853740 3	CABLE	1		
31	85	853816 1	CAP	2		
32	84	853740 4	BATTERY WIRE	1		
33	85	853816	CAP	1		
34	10	16211 1	BOLT	1		
35	54	813275	CLAMP	1		
36	10	16223 1	BOLT	1		