



5804

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	91	853996 6	TOOL	1		
2	91	853996 8	TOOL	1		
3	91	803133 14	CLUTCH PIN SNAP TOOL	1		
4	23	95286 23	COLLAR	1		
5	25	16177 3	O-RING	1		
6	91	803133 10	MEASURING TOOL SHAFT	1		
7	91	803133 11	BEVEL GEAR BEARING PULLER	1		
8	12	16140 11	WASHER	1		
9	11	853722 21	NUT	1		
10	91	803133 12	CLAMP TOOL-BACKLASH MEASU	1		
11	10	803134	BOLT-FOR MOUNTING THE SET	4		
12	91	803133 13	PLATE TOOL-DIAL GAUGE	1		
13	91	853996 4	BEVEL GEAR BEARING PULLER	1		
14	11	853722 20	NUT	1		
15	12	16140 10	WASHER	1		
16	91	803133 2	FLANGE	1		
17	91	803133 8	SHAFT STOPPER TOOL	1		
18	91	803133 3	SHAFT	1		
19	91	803133 4	GUIDE TOOL	1		
20	91	803133 5	RETAINER TOOL	1		
21	91	803133 6	FLANGE	1		
22	91	803133 9	SHAFT STOPPER TOOL	1		
23	91	803133 7	GUIDE TOOL	1		
24	91	853996 12	WRENCH TOOL	1		
25	91	803133 1	SOCKET TOOL	1		
26	91	803133 15	WRENCH TOOL	1		
27	91	853996 2	PISTON PIN TOOL	1		
28	91	803133	PISTON RING TOOL	1		
29	91	804761	FLYWHEEL PULLER KIT	1		
.	91	895212	TOOL, Bearing Outer Press Rod	1		
.	91	895213	TOOL, Bearing Outer Press Plate	1		
.	91	895214	TOOL, Bearing Outer Press Guide	1		
.	91	895215001	TOOL, Bevel Gear A Set	1		
.	91	895217	TOOL, Conedisk Spring, D=12	1		
.	91	895218001	TOOL, Shimming Gauge	1		
.	91	895219	TOOL, Thickness Gauge	1		
.	91	804552001	TOOL	1		
.	91	895220	TOOL, Flywheel Stripper	1		