



					Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote	
1	1427	5611A	CLAMP BRACKET ASSEMBLY (M/	2			
1	1427	5611A	CLAMP BRACKET ASSEMBLY (EL	2			
2	10	90470A	THUMB SCREW ASSEMBLY (M/	2			
2	10	78492A	THUMB SCREW ASSEMBLY (EL	2			
3	10	78495	SCREW, WASHER TO THUMB	2			
4	12	78493	WASHER, THUMB SCREW	2			
5		75043	CAP, THUMB SCREW (MANU/	2			
6	17	49930A	TILT LOCK PIN ASSEMBLY	1			
7	23	59623	SPACER, CLAMP BRACKET STU	1			
8	16	59625	STUD, CLAMP BRACKET	1			
9	13	26393	LOCKWASHER, CLAMP BRACKET	2			
10	11	28770	NUT, CLAMP BRACKET STUD	2			
11		74528	TILT TUBE - CLAMP BRACKET TC	1			
12	12	52864	WASHER, CLAMP BRACKET TO S	6			
13	11	56041	NUT, TILT TUBE	2			
14		53078	CAP, PLASTIC - TILT TUBE	2			
15	10	68298	BOLT	2	CLAMP BRACKET TO BOAT TRA		
16	12	68410	WASHER, CLAMP BRACKET BOL	2			
17	11	99405	NUT, CLAMP BRACKET BOLT	2			
18		88798A	SWIVEL PIN ASSEMBLY (SHORT	1	MANUAL		
18		88798A	SWIVEL PIN ASSEMBLY (LONG	1	MANUAL		
18		69540A	SWIVEL PIN ASSEMBLY (SHORT	1	ELECTRIC		
18		69540A	SWIVEL PIN ASSEMBLY (LONG	1	ELECTRIC		
19		30711	BUMPER, STEERING ARM	1			
20	10	66897	SCREW, UPPER MOUNT TO STE	2			
21		62297	BUMPER, STEERING ARM	1	MANUAL		
22		76535	BRACKET, RIDE-GUIDE ATTACHI	1	MANUAL		
23	10	34352	SCREW, BRACKET TO STEERING	2	MANUAL		
24		76533	STRAP, BRACKET SCREW	1	MANUAL		
25	12	52865	WASHER, SWIVEL PIN	1			
26	1481	7656A	SWIVEL BRACKET ASSEMBLY (S	1			
26	1480	7655A	SWIVEL BRACKET ASSEMBLY (L	1			
27	26	32911	OIL SEAL, SWIVEL BRACKET	2			
28	22	74036	GREASE FITTING - SWIVEL BR.	3			
29		47913A	LEVER ASSEMBLY, TILT LOCK - F	1			
30	10	69087	SCREW	2	TILT LOCK AND STOP LEVER TI		
31	11	29250	NUT, TILT LOCK AND STOP LEV	2			
32		47912A	LEVER ASSEMBLY, TILT TOP - S	1			
33	23	47911	BUSHING, TILT LOCK AND STOP	2			
34	13	34632	WASHER, WAVE - TILT LOCK AN	2			
35	12	56720	WASHER, TILT LOCK AND STOP	2			