



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
		78551A 4	STEERING HANDLE ASSEMBLY	1		
1		48416	CAP, STEERING HANDLE GRIP	1		
2	11	20586	NUT, STEERING HANDLE ARM	1		
3	12	21631	WASHER, STEERING HANDLE	1		
4		58192A 1	GRIP, STEERING HANDLE ARM	1		
5		48414	HOUSING, DRIVE WHEEL - STE	1		
6		48516A 1	DRIVE WHEEL AND ROD ASSE	1		
7		48405	ARM, STEERING HANDLE	1		
8		48519	PLATE, COVER - DRIVE WHEEL	1		
9	27	48518	GASKET, COVER PLATE	1		
10	10	28192	SCREW	4	DRIVE WHEEL COVER PLATE F.	
11		78551 2	CONDUIT, CABLE	1		
12		48520	CABLE, THROTTLE	1		
13		89578	CONNECTOR, CONTROL LINKA	1		
14	10	89601	SCREW, SET - THROTTLE CAB	1		
15		89566	TUBE, THROTTLE CABLE GUID	1		
16		29880	GUIDE, THROTTLE CABLE	1		
17		20007	ANCHOR, THROTTLE CABLE	1		
18	10	20518	SCREW, THROTTLE CABLE AN	2		
19		48404	BRACKET, STEERING HANDLE	1		
20		48416	CAP, STEERING HANDLE BRAC	1		
21	10	48476	SCREW	1	STEERING HANDLE BRACKET 1	
22	12	48477	WASHER, STEERING HANDLE	1		
23	12	48526	WASHER, NYLON - HANDLE BF	1		
24	23	28919	BUSHING, NYLON - HANDLE BF	2		
25	23	48525	SPACER, STEERING HANDLE E	1		
26	12	48527	WASHER, NYLON - HANDLE BF	1		
27	13	48478	WAVE WASHER, STEERING HA	2		
28	12	49636	WASHER, NYLON - HANDLE BF	1		
29	11	20220	NUT, STEERING HANDLE BRAI	1		
30	10	35786	SCREW, BRACKET TO ENGINE	2		
31	14	31828	TAB WASHER, BRACKET SCRE	2		
32		78812A 1	DETENT, SHIFT LEVER	1		
33	10	48409	SCREW	2	SHIFT LEVER DETENT TO HANI	
34		48521	SHIFT LEVER	1		
35	23	48237	BUSHING, NYLON - SHIFT LEV	1		
36	12	34931	WASHER, SHIFT LEVER	1		
37	11	34863	NUT, SHIFT LEVER TO STEERI	1		
38		49563	ROD, SHIFT	1		
39		48419	ROD END, SHIFT ROD	1		
40	22	48476	BUSHING, NYLON, SHIFT ROD	1		