



5262

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	4019	825239T13	TOP COWL	1	(Black)(Electric)	
1	4019	825239T14	TOP COWL	1	(Silver)(Electric)	
2	4019	825239T11	TOP COWL	1	(Black)(Manual)	
2	4019	825239T12	TOP COWL	1	(Silver)(Manual)	
3		813549F 3	COWL SUPPORT BRACKET	1	(Rear)	
4		828433	SPACER-BRACKET	1		
5	10	832086 30	SCREW	3		
6	11	40063 2	NUT	3		
7		18173	BRACKET ASSEMBLY, Latch Rc	1		
8	10	40067 31	SCREW, (M6 x 16)	2		
9		813546003	MOUNT	3		
10		47341A11	ROPE AND HANDLE KIT, Manu.	1		
11		828468	COWL SUPPORT BRACKET	1	(Front)	
12		828503	LATCH KEEPER	1		
13	10	832086 16	SCREW	3		
14	11	40063 2	NUT	1		
15		892844	DUCT, Air Inlet	1		
16		NSS	NOT SOLD SEPARATE, Inductic	1		
17	10	F2317	SCREW, (.250-20 x .875)	2		
18		831905	SEAL	1		
19		813504A 1	GAUGE KIT, Oil Level	1	(Electric)	
20		813505	GROMMET	1	(Electric)	
21		11317 1	RETAINER	1	(Electric)	
22	11	11316 1	NUT	1	(Electric)	
23		828180A 1	SOUND BLANKET KIT (Hot Glue	1		
23		828180A02	SOUND BLANKET KIT, (Pre-App	1		
24		NSS	NOT SOLD SEPARATE, Starbr	1		
25		NSS	NOT SOLD SEPARATE, Port a	1		
26		NSS	NOT SOLD SEPARATE, Tape	1		
27	37	824093 16	DECAL, F-N-R Shift	1		