



9802

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		19608A14	ATTACHING KIT, Engine Steering	1	(Non-Handle)	
2	10	823919	SCREW, (.375-24 x 1.500)	1	(Non-Handle)	
3	12	71970	WASHER, (.390 x .546 x .12)	1	(Non-Handle)	
4	12	37828	WASHER, (.390 x .625 x .062)	2	(Non-Handle)	
5	11	826709113	NUT, (.375-24)	2	(Non-Handle)	
6		822397	PUCK	1	(Non-Handle)	
7	3410	827402T 5	SWIVEL BRACKET	1		
8	23	821771 1	BUSHING, Upper	1		
9	22	74036	FITTING, Grease	3	(Quanty of 4 on Handle Version)	
10	23	821777	BUSHING, Lower	1		
11	26	822404	SEAL	1		
12		NSS	NOT SOLD SEPARATE, Decal-Sea	1		
13		88238A11	CABLE ASSEMBLY	1	(A = To Screw on Bottom Yoke)	
14	12	19619	WASHER	1		
15	10	40089 10	SCREW, (M8 x 10)	1	(Handle)	
15	10	40011149	SCREW, (M8 x 25)	1	(Non-Handle)	
16		828245 1	SEAL	1	(Non-Handle)	
17		19624A 1	SEAL KIT	1	(Non-Handle)	
18	25	29619	O-RING, (.583 x .103)	1	(Non-Handle)	
19	23	78861	SPACER	1	(Non-Handle)	
20	12	19619	WASHER	1		
21		19614 1	TILT TUBE	1		
22	11	858869	NUT, (.875-14)	2		
23	37	823701 1	DECAL, Co-Pilot	1		
24	17	821539	PIN, Trilobe	1		
25	23	823507	BUSHING	2		
26	17	822480	PIN, Pivot, Upper	1		
27	10	878607	SCREW, (#10-16 x .375)	1		