



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1580	5557A 1	DRIVE SHAFT HOUSING ASSEMBLY	1	SERIAL #9210595 AND BELOW	
1	1580	6673A 2	DRIVE SHAFT HOUSING ASSEMBLY	1	SERIAL #9210596 AND UP	
2	16	68927	STUD, DRIVE SHAFT HOUSING	1		
2	16	75321	STUD, DRIVE SHAFT HOUSING	1		
3	10	28634	SCREW, GREASE FILLER	1		
4	12	20260	WASHER, GREASE FILLER SCF	1		
5	32	68979	WATER TUBE (SHORT SHAFT)	1		
5	32	75308	WATER TUBE (LONG SHAFT)	1		
6	26	36556	SEAL, WATER TUBE	1		1
7	12	36554	WASHER, WATER TUBE SEAL	1		
8		68976	CLAMP, CO-PILOT	1		
9		74480	MOUNT, RUBBER	1	DRIVE SHAFT HOUSING (TOP)	
9		74481	MOUNT	1	RUBBER - DRIVE SHAFT HOUSING	
10	23	74308	BUSHING, RUBBER MOUNT	2		
11		68990A 1	BRACKET ASSEMBLY, STEERING	1		
12	10	68918	SCREW, STEERING ARM BRACKET	4		
13	11	35814	NUT, GEAR HOUSING STUD	1		
13		75311	ADAPTOR, DRIVE SHAFT HOUSING	1		
13		76265	BEARING BLOCK, DRIVE SHAFT	1		